Your **HTC** One® VX

Inserting your microSIM and microSD® cards

IMPORTANT: USE A STANDARD MICROSIM ONLY.
Inserting a smaller size SIM (such as nanoSIM with an adapter or a modified SIM) may damage the card slot or cause the card to not fit properly.



1. With your finger, open the back cover from the small opening at the bottom.



2. With your microSIM card's gold contacts facing down and cut-off corner facing in, insert the microSIM into the SIM slot and push it in until it clicks into place.



3. With your microSD card's gold contacts facing down, insert the microSD card into the storage card slot and push it all the way in.



4. To replace the back cover, align the top part of the back cover with the back panel first. Then gently press the back cover and run your thumbs along the sides up to the bottom.

   Make sure that the back cover is tight and there are no gaps or bulges on any side.

Removing your microSIM card



To remove the microSIM card, press and hold the SIM tab, and then carefully slide the microSIM card out from the SIM slot.

Important reminders

Charge the battery

The battery in your phone hasn't been charged yet. Please use the supplied power adapter to do a full charge before you start using your phone. Also, please don't try to take your phone apart. (If you do, it may invalidate your warranty.)

Choose a rate plan wisely

Depending on how you use your phone, it can use up a lot of Internet bandwidth really quickly. Before you use your phone, we strongly recommend that you contact your mobile operator about data rates. Using data services while roaming will be costly. Check with your mobile operator for data roaming rates before you use data roaming.

Know about privacy laws

Some countries have strict laws about how and when you can record phone conversations. It's a good idea to find out what the laws are where you live before you use your phone's recording feature.

And finally, a few important words from our legal team (LIMITATION OF DAMAGES)

To the maximum extent permitted by applicable law, in no event shall HTC or its affiliates be liable to you, any user, or third party for any indirect, special, consequential, incidental or punitive damages of any kind, arising in contract, tort, or otherwise, including, but not limited to, injury, loss of revenue, loss of goodwill, loss of business opportunity, loss of data, and/or loss of profits, regardless of the foreseeability thereof or whether HTC or its affiliates have been advised of the possibility of such damages. And in no event shall the total liability of HTC or its affiliates exceed the amount received from you, regardless of the legal theory under which the cause of action is brought. The foregoing does not affect any statutory rights which may not be disclaimed.

© 2013. All rights reserved. HTC Corporation. HTC, the HTC logo, and HTC One are trademarks of HTC Corporation. Beats Audio, the Beats Audio logo, and the Circle B logo are trademarks of Beats Electronics, LLC. microSD is a trademark or registered trademark of SD-3C, LLC in the United States, other countries or both.

htc.com

91H0xxxx-xxM Rev.A